


QUICK INSTALL & CLEARANCES

For full installation directions/clearances please refer to the corresponding User Manual and/or Installation Guide.

LSCE305ST

30" RADIANT COOKTOP



MODEL	A	B	C	D	E	F		G	H	I		J	K	L
						Min.	Max.			Min.	Max.			
30" Cooktop	30 ²⁷ / ₃₂ "	21 ²³ / ₃₂ "	3 ³ / ₄ "	28 ¹³ / ₁₆ "	19 ⁵ / ₈ "	29 ³ / ₈ "	20 ¹ / ₄ "	13 ¹ / ₁₆ "	13"	5 ²³ / ₃₂ "	2 ¹ / ₂ "	24"		
36" Cooktop	36 ¹³ / ₁₆ "	22 ¹⁵ / ₃₂ "	3 ³ / ₄ "	33 ²⁷ / ₃₂ "	19 ²³ / ₃₂ "	34 ⁹ / ₁₆ "	20 ¹ / ₄ "	13 ¹ / ₁₆ "	13"	5 ²³ / ₃₂ "	2 ¹ / ₂ "	24"		